

License Information

Information in this document is subject to change without notice and does not represent a commitment on the part of CIMCO Integration. The software described in this document may be used or copied only in accordance with the terms of the license. The purchaser may make one copy of the software for a backup, but no part of this user manual may be reproduced, stored in a retrieval system, or transmitted in any form or by any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's personal use, without prior written permission from CIMCO Integration.

TERMS OF USE FOR SOFTWARE

Software: CNC-Calc v2

Version: 2.x.x

Date: October 2004

Copyright © 2004 by CIMCO Integration

Notice:

CIMCO Integration reserves the right to make changes to the CNC-Calc v2 Software at any time and without notice.

Software License

You have the right to use the number of licenses of the enclosed program, which you have bought from CIMCO Integration. You may not distribute copies of the program or related documentation to any persons or companies. You may not modify the program or related documentation without the prior written consent of CIMCO Integration.

Disclaimer of all Warranties and Liability

CIMCO Integration makes no warranties, either express or implied, with respect to the software, its quality, performance, merchantability, or fitness for any particular purpose. The entire risk as to its quality and performance is with the buyer. Should the CNC-Calc v2 software prove defective following its purchase, the buyer (and not CIMCO Integration, its distributor, or its retailer) assumes the entire cost of all necessary

servicing, repair, of correction and any incidental or consequential damages. In no event will CIMCO Integration be liable for direct, indirect, or consequential damages resulting from any defect in the software, even if CIMCO Integration has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of implied warranties or liability for incidental or consequential damages, so the above limitation or exclusion may not apply to you.

NOTICE: The accompanying software is confidential and proprietary to CIMCO Integration. No use or disclosure is permitted other than as expressly set forth by written license with CIMCO Integration.

Copyright © 2004 CIMCO Integration. All rights reserved.

THIS SOFTWARE CONTAINS CONFIDENTIAL INFORMATION AND TRADE SECRETS OF CIMCO INTEGRATION. USE, DISCLOSURE, OR REPRODUCTION IS PROHIBITED WITHOUT THE PRIOR EXPRESS WRITTEN PERMISSION OF CIMCO INTEGRATION.

The CIMCO Logo is a trademark of CIMCO Integration. Microsoft, Windows, and Windows NT are registered trademarks of Microsoft Corporation. Other brand and product names are trademarks or registered trademarks of their respective holders.

Contacting CIMCO Integration

Address:

CIMCO Integration I/S
Maglebjergvej 6
DK-2800 Lyngby
Denmark

Phone: +45 4585 6050

Fax: +45 4585 6053

E-mail: info@cimco-software.com

Web: <http://www.cimco-software.com>

CNC-Calc v2

Installing CNC-Calc v2	4
Overview	5
Mouse functions.....	7
Toolbars	8
Tools	8
Points and Lines	9
Arcs and Circles	10
Modify.....	12
Menus	14
File menu	14
CNC-Calc menu	14
Draw Points / Lines	14
Draw Arcs / Circles.....	16
Draw Special	17
Modify	18
Creating toolpath contours	21
Drilling holes	25
Configuring CNC-Calc	28
Main configuration.....	28
Color configuration	31
Other configurations that affect CNC-Calc	32


Installing CNC-Calc v2

CNC-Calc v2 is installed as part of CIMCO Edit v5. Please see the CIMCO Edit v5 documentation for installation instructions.

If you are upgrading and existing installation (without CNC-Calc v2), then you do not need to reinstall CIMCO Edit v5, you only need to copy the new keyfile (named "license.key) to the appropriate directory.

Overview

CNC-Calc v2 can draw 2D geometry, and can produce NC code in ISO and Heidenhain conversational format for contours and drilling cycles. The program window looks like this (with an empty drawing pane):



The toolbars can be arranged as desired by dragging them around. They can be docked along any edge of the program window, in any order, or they can be placed floating on top of the program window or outside the program window.

To the left of the drawing pane, you see the *CNC-Calc* and *Element Info* panes. The CNC-Calc pane shows coordinate entry fields and other information about the activity you are performing at any give time, while the *Element Info* pane shows the statistics of the element you are hovering the mouse over. To the right, you can see an example of *Element Info* pane display.


Element Info - Arc	
Center X:	-55.785
Center Y:	29.132
Radius:	28.507
Length:	74.026
Start Angle:	91.650
End Angle:	240.433
Sweep:	148.783

Most of the functions in CNC-Calc v2 can be accesses both through the toolbars and through the CNC-Calc menu, though a few functions are accessed in the File menu in CIMCO Edit v5. The manual will first describe the mouse functions, then the toolbars and menus.

Mouse functions

The mouse has a number of functions:

Left button: Selects whatever is described in the lower left corner of the program window.

Middle button (on most mice, pressing the scroll wheel): Fit the geometry to the graphics area. This can also be done with the  icon.

Right button: Drag the drawing across the graphics area by holding down the right mouse button as you drag the mouse.


Scroll wheel: Zoom in and out, centered on the cursor position.


Toolbars


Tools




The **Tools** toolbar handles file operations, toolpath functions, zoom, snap and configuration access. The functions on the *Tools* toolbar are directly in the CNC-Calc menu.


 *New Drawing* will clear the graphics area (you will get a chance to save any unsaved changes). *New* can also be accessed with Ctrl-N.


 *Open Drawing* will open an existing CNC-Calc v2 file. *Open* can also be accessed with Ctrl-O. The downwards arrow next to the open icon gives access to a recent files list, making it easy to reopen a file which you have been editing recently.


 *Save* saves the drawing to your hard disk. If it is the first time you save the drawing, you will be prompted for a file location and name. *Save* can also be accessed with Ctrl-S.


 *Layout Toolpath* lets you chain a toolpath contour, and then export it as ISO or Heidenhain Conversational NC code.

 *Drill Hole* lets you select drill points and a drill cycle, and then export it as ISO or Heidenhain Conversational NC code.


 *Zoom in* centered on the middle of the graphics area. *Zoom in* can also be accessed with Page Down.


 *Zoom out* centered on the middle of the graphics area. *Zoom out* can also be accessed with Page Up.

 *Zoom All* fits the drawing to the graphics area. This can also be done by clicking the middle button on the mouse (on most mice, pressing the scroll wheel), or with Ctrl-End.

 *Zoom Window* lets you zoom in on an area, which you select by first clicking at one corner, then dragging the rectangle and clicking at the opposite corner.





 *Snap to Grid* snaps to the grid points.

 *Snap to Points* snaps to points drawn by the user.


 *Snap to Center Points* snaps to the centers of circles and arcs.









 *Snap to Mid points* snaps to the midpoints of elements.





 *Snap to End points* snaps to the endpoints of elements.

-  *Snap to Intersections* snaps to the intersections between elements.
-  *Enable All Snap Types* activates all snap types.
-  *Disable All Snap Types* deactivates all snap types.
-  *Setup CNC-Calc* lets you access the configuration for CNC-Calc.


Points and Lines






 The line toolbar draws lines defined in different ways, and also points. The functions in the *Points / Lines* toolbar can be found under *Draw Points / Lines* in the menu.









-  *Point* will draw a point at the selected position.
-  *Between 2 Points* will draw a line between the two selected points.
-  *Vertical* will draw a vertical line. The first point selected defines the starting point (and the X coordinate), the second point selected defines the length (and need not be directly above or below the first point).
-  *Horizontal* will draw a horizontal line. The first point selected defines the starting point (and the Y coordinate), the second point selected defines the length (and need not be directly to the left or right of the first point).
-  *Polar* lets you select the starting point of a line, and you then select (or write) the angle and length of the line.
-  *Perpendicular* draws a line perpendicular to another line. You first select the line your new line is to be perpendicular to, then the starting point of your new line. You then select the length of your new line, and last you select in which direction from the starting point your new line is to go.
-  *Parallel* draws a line parallel to another line. You first select the line your new line is to be parallel to, then the starting point of your new line. You then select the length of your new line, and last you select in which direction from the starting point your new line is to go.
-  *Bisector* draws a line bisecting two other lines, i.e. a line that halves the angle between two lines. You first select the two line you want to bisect, then you select the length of your new line (from the intersection of the two lines you are bisecting), and last you select which of the four possible solutions you want to keep.

-  *Tangent Two Elements* lets you draw a line tangent to two circles or arcs. You select the two circles or arcs your new line is to be tangent to, and then you select which of the solutions you want to keep.
-  *Tangent Angle* draws a line tangent to an arc or circle, at a selected angle. You first select the arc or circle your new line is to be tangent to, then the angle and length, and last you select which of the two solutions you want to keep.
-  *Tangent Through Point* draws a line tangent to an arc or circle, to a selected point. You first select the arc or circle your new line is to be tangent to, then the point it is to go through, and last you select which of the two solutions you want to keep.
-  *Rectangle* draws a rectangle where you select the two opposite corners. It is possible to define a corner radius for the rectangle (the corner radius is ignored if there is not room for it).


Arcs and Circles












 The *Arcs / Circles* toolbar lets you draw full circles (360 degree arcs), arcs and bolt patterns. The functions in the *Arcs / Circles* toolbar can be found under *Draw Arcs / Circles* and *Draw Special* in the menu.

-  *Center Radius* lets you define the center of the circle, followed by the radius.
-  *Two Points* lets you define the circle by selecting two (diametrically opposite) points.
-  *Three Points* lets you define the circle by selecting three points on the periphery of the circle.
-  *Center Diameter* lets you define the center of the circle, followed by the diameter.
-  *Tangent Two Elements* lets you define a circle tangent to two elements, of a defined radius. You first write the radius, then you select the two elements the circle is to be tangent to. Last you select which of the solutions you want to keep.

-  *Tangent Center on Line* lets you define a circle tangent to one element, with its center on a line, of a defined radius. You first write the radius, then you select the line the center is to be on, and the element the circle is to be tangent to. Last you select which of the solutions you want to keep.
-  *Tangent through Point* lets you define a circle tangent to one element, through a point, of a defined radius. You first select the point the circle is to go through, then write the radius, and select the element the circle is to be tangent to. Last you select which of the solutions you want to keep.
-  *Tangent Three Elements* defines a circle tangent to three elements. You select the three elements the circle is to be tangent to, and then you select which of the solutions you want to keep.
-  *Two Points* lets you draw an arc by selecting the endpoints of the arc, entering the radius, and selecting which solution you want to keep.
-  *Three Points* lets you draw an arc by selecting three points. Note, that the arc created will not cross the zero degree point (3 o'clock); The order the three points are selected in does not matter.
-  *Start and End Angles* lets you define an arc by its center point, radius, starting angle and end angle.
-  *Rectangular Bolt Hole Pattern* defines a rectangular bolt pattern. You select the start point (one of the corners), and then enter the step in X, step in Y, number of holes in X, number of holes in Y and the hole diameter.
-  *Circular Bolt Hole Pattern* defines a circular bolt pattern. You select the center of the bolt pattern, select the radius of the bolt pattern, and then enter the start angle, step angle, number of holes and the hole diameter.

Modify

 The modify toolbar modifies the geometry in different ways. The functions in the *Modify* toolbar can be found under *Modify* in the menu.

-  *Trim To Intersection* will trim the selected element to the nearest intersection(s). Select the element to be trimmed on that part to be removed; It is then trimmed to the intersection(s) nearest the point where it was selected. The trimmed element is also broken in two, if there are intersections on both sides of the selected point.
-  *Trim One Element* will trim one element to another. Select the element to be trimmed first, on the side to be kept, then select the element to trim to.
-  *Trim Two Elements* will trim two elements to each other. Select the two elements to be trimmed, on the side to be kept.
-  *Fillet Elements* creates a fillet between two elements, with a fillet radius the user selects. It is optional, whether the two elements should also be trimmed to the fillet.
-  *Break Elements* will divide an element into two pieces. First select the element to be broken into two, then select the point at which it should be divided.
-  *Join Elements* will join two selected elements into one. The two elements have to be elements that can be joined into one element, of course.
-  *Delete* will delete the elements you select. They can be restored with the *Undo* function (the  icon or *Undo* under *Modify* in the menu).
-  *Offset Elements* will offset the elements you select by a specified distance. It is optional whether the original should be kept.
-  *Mirror Elements* will mirror the elements you select about a line selected as the mirror axis.
-  *Translate Elements* will translate the elements you select along a vector defined by selecting two points. It is optional whether the original should be kept, and it is possible to create multiple copies, where each copy is translated one step further along the selected vector.



Rotate Elements will create one or more copies of the selected elements, rotated around a selected point, at a specified angle per copy. It is optional whether the original should be kept.



Scale Elements will create one or more copies of the selected elements, scaled about a selected point by a specified scale factor. It is optional whether the original should be kept.



Undo will undo one or more operations. This can mean deleting elements created, restoring deleted elements, and/or undoing modifications to elements. Undo can also be accessed with Ctrl-Backspace.

Menus

Most of the CNC-Calc v2 functions that are accessed through the CNC-Calc menu, but there are a few that are accessed through the *File* menu.

File menu

Close closes the active file. If the active file has been modified, then the user will be prompted to save it. *Close* can also be accessed with Ctrl-F4.

Close All closes all open files. If any files have been modified, then the user will be prompted to save them.

Save saves the drawing to your hard disk. If it is the first time you save the drawing, you will be prompted for a file location and name. *Save* can also be accessed with Ctrl-S.

Save As will save the drawing under a different name.

Exit closes CIMCO Edit v5, and thus also CNC-Calc v2. If any files have been modified, then the user will be prompted to save them. *Exit* can also be accessed with Alt-F4 (Alt-F4 is a Windows standard).

CNC-Calc menu

New Drawing will clear the graphics area (you will get a chance to save any unsaved changes). *New* can also be accessed with Ctrl-N.

Open Drawing will open an existing CNC-Calc v2 file. *Open* can also be accessed with Ctrl-O.

Draw Points / Lines

Point will draw a point at the selected position

Between 2 points will draw a line between the two selected points.

Vertical will draw a vertical line. The first point selected defines the starting point (and the X coordinate), the second point selected defines the length (and need not be directly above or below the first point).

Horizontal will draw a horizontal line. The first point selected defines the starting point (and the Y coordinate), the second point selected defines the length (and need not be directly to the left or right of the first point).

Polar lets you select the starting point of a line, and you then select (or write) the angle and length of the line.

Perpendicular draws a line perpendicular to another line. You first select the line your new line is to be perpendicular to, then the starting point of your new line. You then select the length of your new line, and last you select in which direction from the starting point your new line is to go.

Parallel draws a line parallel to another line. You first select the line your new line is to be parallel to, then the starting point of your new line. You then select the length of your new line, and last you select in which direction from the starting point your new line is to go.

Bisector draws a line bisecting two other lines, i.e. a line that halves the angle between two lines. You first select the two line you want to bisect, then you select the length of your new line (from the intersection of the two lines you are bisecting), and last you select which of the four possible solutions you want to keep.

Tangent Two Elements lets you draw a line tangent to two circles or arcs. You select the two circles or arcs your new line is to be tangent to, and then you select which of the solutions you want to keep.

Tangent Angle draws a line tangent to an arc or circle, at a selected angle. You first select the arc or circle your new line is to be tangent to, then the angle and length, and last you select which of the two solutions you want to keep.

Tangent Through Point draws a line tangent to an arc or circle, to a selected point. You first select the arc or circle your new line is to be tangent to, then the point it is to go through, and last you select which of the two solutions you want to keep.

Rectangle draws a rectangle where you select the two opposite corners. It is possible to define a corner radius for the rectangle (the corner radius is ignored if there is not room for it).

Draw Arcs / Circles

Two Points lets you define the circle by selecting two (diametrically opposite) points.

Three Points lets you define the circle by selecting three points on the periphery of the circle.

Center Radius lets you define the center of the circle, followed by the radius.

Center Diameter lets you define the center of the circle, followed by the diameter.

Tangent Two Elements lets you define a circle tangent to two elements, of a defined radius. You first write the radius, then you select the two elements the circle is to be tangent to. Last you select which of the solutions you want to keep.

Tangent Three Elements defines a circle tangent to three elements. You select the three elements the circle is to be tangent to, and then you select which of the solutions you want to keep.

Tangent Center on Line lets you define a circle tangent to one element, with its center on a line, of a defined radius. You first write the radius, then you select the line the center is to be on, and the element the circle is to be tangent to. Last you select which of the solutions you want to keep.

Tangent through Point lets you define a circle tangent to one element, through a point, of a defined radius. You first select the point the circle is to go through, then write the radius, and select the element the circle is to be tangent to. Last you select which of the solutions you want to keep.

Two Points lets you draw an arc by selecting the endpoints of the arc, entering the radius, and selecting which solution you want to keep.

Three Points lets you draw an arc by selecting three points. Note, that the arc created will not cross the zero degree point (3 o'clock); The order the three points are selected in does not matter.

Start and End Angles lets you define an arc by its center point, radius, starting angle and end angle.

Draw Special

Rectangular Bolt Hole Pattern defines a rectangular bolt pattern. You select the start point (one of the corners), and then enter the step in X, step in Y, number of holes in X, number of holes in Y and the hole diameter.

Circular Bolt Hole Pattern defines a circular bolt pattern. You select the center of the bolt pattern, select the radius of the bolt pattern, and then enter the start angle, step angle, number of holes and the hole diameter.

Modify

Trim To Intersection will trim the selected element to the nearest intersection(s). Select the element to be trimmed on that part to be removed; It is then trimmed to the intersection(s) nearest the point where it was selected. The trimmed element is also broken in two, if there are intersections on both sides of the selected point.


Trim One Element will trim one element to another. Select the element to be trimmed first, on the side to be kept, then select the element to trim to.

Trim Two Elements will trim two elements to each other. Select the two elements to be trimmed, on the side to be kept.

Fillet Elements creates a fillet between two elements, with a fillet radius the user selects. It is optional, whether the two elements should also be trimmed to the fillet.

Break Elements will divide an element into two pieces. First select the element to be broken into two, then select the point at which it should be divided.

Join Elements will join two selected elements into one. The two elements have to be elements that can be joined into one element, of course.

Delete will delete the elements you select. They can be restored with the *Undo* function (the  icon or *Undo* under *Modify* in the menu).

Offset will offset the elements you select by a specified distance. It is optional whether the original should be kept.

Mirror Elements will mirror the elements you select about a line selected as the mirror axis.

Translate Elements will translate the elements you select along a vector defined by selecting two points. It is optional whether the original should be kept, and it is possible to create multiple copies, where each copy is translated one step further along the selected vector.

Rotate Elements will create one or more copies of the selected elements, rotated around a selected point, at a specified angle per copy. It is optional whether the original should be kept.

Scale Elements will create one or more copies of the selected elements, scaled about a selected point by a specified scale factor. It is optional whether the original should be kept.

Undo will undo one or more operations. This can mean deleting elements created, restoring deleted elements, and/or undoing modifications to elements. Undo can also be accessed with Ctrl- Backspace.

Zoom in centered on the middle of the graphics area. *Zoom in* can also be accessed with Page Down.

Zoom out centered on the middle of the graphics area. *Zoom out* can also be accessed with Page Up.

Zoom All will fit the drawing to the graphics area. This can also be done by clicking the middle button on the mouse (on most mice, pressing the scroll wheel), or with Ctrl-End.

Zoom Window lets you zoom in on an area, which you select by first clicking at one corner, then dragging the rectangle and clicking at the opposite corner.

Snap to Grid snaps to the grid points.

Snap to Points snaps to points drawn by the user.

Snap to Center points snaps to the centers of circles and arcs.

Snap to Mid points snaps to the midpoints of elements.

Snap to End points snaps to the endpoints of elements.

Snap to Intersections snaps to the intersections between elements.

Enable All Snap Types activates all snap types.

Disable All Snap Types deactivates all snap types.


Layout Toolpath lets you chain a toolpath contour, and then export it as ISO or Heidenhain Conversational NC code.

Drill Holes lets you select drill points and a drill cycle, and then export it as ISO or Heidenhain Conversational NC code.

Setup CNC-Calc lets you access the configuration for CNC-Calc.


Creating toolpath contours

Before creating a toolpath or drilling holes, you should select the correct machine type in CIMCO Edit v5. This can also be done later, though.

To create a toolpath, you first need to have the geometry drawn in the graphics area. You then select **CNC-Calc** → **Layout Toolpath** or the  icon to start defining a toolpath contour. This will show the toolpath pane to the left in the window, shown to the right.



At the top of the toolpath pane, you can give a name for your toolpath. The name will be output as a comment at the start of the toolpath.

First you define where your machine zero is in the drawing. This is often X0 Y0 in your drawing, but any point can be entered.



The screenshot shows the 'Create Toolpath' dialog box with the following fields and options:

- Name: [Text Input Field]
- Machine Zero X: [Text Input Field] 0.0000 [Target Icon]
- Machine Zero Y: [Text Input Field] 0.0000 [Target Icon]
- Depth: [Text Input Field] -5
- Single Step
- [Retract] [Lead In/Out]
- [Back] [New]
- [Export Editor] [Export Clipboard]

You must then select the start point of the contour. This is best done by setting End Points as the only active snap (use the icons **Cancel All**  and **End Points**  from the *Snap* toolbar), as the start point of the contour has to be at the end point of an element.

CNC-Calc v2 now highlights all elements that have an endpoint at the selected start point, and you have to select which of them you want the contour to start along. The behavior then depends on whether the *Single Step* option is selected.

If *Single Step* is selected, then it is necessary to click on each element needed in the contour; CNC-Calc will highlight the possible selections.

If *Single Step* is not selected, then CNC-Calc will automatically select all elements until the contour is closed or there is a branching (i.e. two

possible direction for the contour). CNC-Calc will then highlight the possible selections for continuing the contour.

When the desired contour has been selected, it is necessary to set the depth of the contour, and you should also set the *Retract* and *Lead In/Out* settings by clicking the appropriate buttons.

For *Retract*, you can set rapid and feed retract heights, as shown to the right. The behavior depends on which of the options are selected, as follows:


None selected: At the start of the contour, there is a positioning at rapid to the start of the contour in X and Y, and a feed move to contour depth. The contour ends at depth (there is no retract).

Rapid Retract selected, Feed Retract not selected: At the start of the contour, there is a positioning at rapid to the start of the contour in X and Y, and a feed move to contour depth. At the end of the contour, there is a rapid move to rapid retract height.

Feed Retract selected, Rapid Retract not selected: At the start of the contour, there is a positioning at rapid to the start of the contour in X and Y, and a feed move to contour depth. At the end of the contour, there is a feed move to feed retract height.

Both selected: At the start of the contour, there is a positioning at rapid to the start of the contour in X and Y, a rapid move to feed retract height and a feed move to contour depth. At the end of the contour, there is a feed move to feed retract height, and a rapid move to rapid retract height.

For *Lead In/Out*, you can set lead in, lead out and cutter compensation in the control, as shown on next page.



The screenshot shows a dialog box titled "Lead in/Lead out". It contains the following controls:

- Lead Side:** A dropdown menu currently set to "Left".
- Compensation:** Two radio buttons, "On" (selected) and "Off".
- Lead In:** A section with a checked "Use Line" checkbox, a "Line Length" text box containing "5.0000", radio buttons for "Perpendicular" and "Tangent" (selected), a checked "Use Arc" checkbox, a "Radius" text box containing "5.0000", and a "Sweep" text box containing "90.00".
- Lead Out:** A section with a checked "Use Line" checkbox, a "Line Length" text box containing "5.0000", radio buttons for "Perpendicular" and "Tangent" (selected), a checked "Use Arc" checkbox, a "Radius" text box containing "5.0000", and a "Sweep" text box containing "90.00".
- Navigation:** Two arrow buttons, ">" and "<".
- Buttons:** "Cancel" and "OK" buttons at the bottom.

Lead Side selects which side the lead in and/or lead out is to be to, and which side the cutter compensation in control is to be to if that is selected.

Compensation selects whether the codes for cutter compensation in control (G41/G42 and G40 for ISO, RR/RL and R0 for Heidenhain conversational) are to be output.

The settings for *Lead In* and *Lead Out* are the same.

Use Line selects that there is to be a line in the lead, and it can be selected whether that line is to be perpendicular or tangent to the next element (the arc of the lead if selected, otherwise the contour). Note: If cutter compensation in control is active, then a lead line of more than the radius of the cutter is usually required, in order to allow the control to activate the cutter compensation before cutting the contour itself.


Use Arc selects that there is to be an arc in the lead, and the radius and sweep in degrees can be set. Note: If cutter compensation in control is active, then the lead arcs usually must have a radius greater than the radius of the cutter.

The two arrows between the *Lead In* and *Lead Out* areas will copy the settings from one lead to the other.

When the toolpath has been defined, you create NC code by clicking either the *Export Editor* or the *Export Clipboard* button. *Export Editor* opens a new editor tab, with the NC code for the toolpath already in the tab, while *Export Clipboard* places the NC code in the Windows clipboard, so it can be pasted into an existing NC program (or any other document, in any Windows application).




Drilling holes


Before creating a toolpath or drilling holes, you should select the correct machine type in CIMCO Edit v5. This can also be done later, though.

To drill holes, you first need to have the geometry drawn in the graphics area (usually in the form of circles or points). You then select *CNC-Calc* → *Drill Holes* or the  icon to start defining drill points. This will show the drilling pane, shown to the right.

At the top of the drilling pane, you can give a name for your drilling operation. The name will be output as a comment at the start of the drilling operation.

First you define where your machine zero is in the drawing. This is often X0 Y0 in your drawing, but any point can be entered.

You then select the positions where you need to drill. This is usually done with snap to circle center and/or snap to points active, and the other snap types off. Select *CNC-Calc* → *Disable All Snap Types* from the menu (or the  icon), then *CNC-Calc* → *Snap to Points* and/or *Snap to Center Points* (or the  and/or  icon) to set the snap settings. Initially, the drill points will be drilled in the order they are selected, but the order can be changed with the *Reorder Circ* and *Reorder Rect* options.




The screenshot shows a dialog box titled "Drilling". It contains the following elements:

- A "Name:" text input field.
- A "Machine Zero X:" label with a checkbox, a text input field containing "0.0000", and a circular icon with an "x" inside.
- A "Machine Zero Y:" label with a checkbox, a text input field containing "0.0000", and a circular icon with a "y" inside.
- A "Drill Parameters" button.
- "Reorder Circ" and "Reorder Rect" buttons.
- "Back" and "New" buttons.
- "Export Editor" and "Export Clipboard" buttons.

When the drill points have been selected, it is time to define which type of drilling cycle is to be used. That is done by clicking the *Drill Parameters* button, which opens the dialog shown to the left.


You select the type of drilling cycle from the dropdown menu at the top, and then fill in the relevant parameters for drill cycle.

To reorder the drill points, you click either the *Reorder Circ* or the *Reorder Rect* button, depending on the reordering method desired. The two reordering methods work like this:



The **Drilling** dialog box contains the following fields and controls:

- Drill Type:** A dropdown menu currently set to "Drilling".
- Depth:** A text input field containing "-2".
- Retract Height:** A text input field containing "50".
- Feedrate:** A text input field containing "300".
- Dwell Time:** A text input field containing "0.0000".
- Depth Increments:** A text input field containing "0.0000".
- Buttons:** "Cancel" and "OK" buttons at the bottom.




The **Order Holes In Circular O...** dialog box contains the following fields and controls:

- Center:**
 - X:** A text input field containing "0.0000".
 - Y:** A text input field containing "0.0000".
- Rotation:**
 - Start Angle:** A text input field containing "0.00".
 - Direction:** Radio buttons for "CW" (selected) and "CCW".
- Movement Pattern:**
 - Radio buttons for "Zigzag" (selected) and "Forth and Back".
- Buttons:** "Cancel" and "OK" buttons at the bottom.

Reorder Circ shows the dialog to the left. *Center* specifies the center the drill points are to be sorted around, *Start Angle* the starting angle of the sorting (the direction to the first hole), and *CW* and *CCW* the direction of the sorting. *Zigzag* will move in a pattern where the tool will move back to near the center once all holes along a give angle have been drilled, while *Forth and Back* will move the drill over to the next angle at the distance from center of the last hole at a given angle.

Reorder Rect shows the dialog to the right. *Primary Axis* is the axis that defines the flow of the drill point order; as the tool moves along the primary axis, drill points that are at the same position on the primary axis are sorted along the secondary axis according to the movement pattern. *Orientation* gives the direction from the first to the last hole for the primary axis; for the secondary axis, it is the direction from first to last hole if *Zigzag* is selected, or the initial direction if *Forth and Back* is selected.



When the drilling operation has been defined, you create NC code by clicking either the *Export Editor* or the *Export Clipboard* button. *Export Editor* opens a new editor tab, with the NC code for the drilling operation already in the tab, while *Export Clipboard* places the NC code in the Windows clipboard, so it can be pasted into an existing NC program (or any other document, in any Windows application).




Configuring CNC-Calc

Perhaps the most important thing to remember when configuring CNC-Calc is that except for the toolbar positions, the configuration is specific to each machine type.

Main configuration

The main configuration is easiest to enter by selecting *CNC-Calc* → *Setup CNC-Calc* or *Setup* → *CNC-Calc* from the menu, or the  icon from the CNC-Calc Tools toolbar. It can also be entered by selecting *Setup* → *Machine / File Types* from the menu or the  icon from the file operations toolbar, and then selecting *CNC-Calc* from the configuration tree. It is important to have selected the correct machine type, and it should be noted, that the selection between ISO and Heidenhain conversational NC code output is made by the template used when creating the machine type. The main configuration dialog can be seen on next page.



The top part of the main configuration are the settings for toolpath output, with the settings for the drawing grid at the bottom. The correct settings for toolpath output depend on the machine and control that is to run the NC code, you should consult the programming manual for the machine if in doubt.

The settings for toolpath output are:

Turning: Select this for turning (lathe) output. This option is unavailable for Heidenhain conversational NC code output.

Diameter programming: Selects whether X axis output is in diameter measurement or in radius measurement. This option is only available if turning (lathe) output is selected.

Arc center is specified as diameter: Selects whether the I value for arcs is specified in diameter measurement or in radius measurement. This option is only available if turning (lathe) output is selected.

Show plot as positive X/I: Selects whether the X/I output is in the X+ or the X- direction. This option is only available if turning (lathe) output is selected.

Always add sign: Selects whether the sign of the coordinate always is output (giving a + sign on positive and zero coordinates), or the sign is only output on negative coordinates.

Modal X/Y values: Selects whether the coordinates are modal or not. Modal coordinates means the coordinates are only output when changed, while non-modal coordinates means both X and Y are output on every line, regardless of whether they are changed or not.

Arc Type:

Absolute arc center: The arc center is given in absolute I and J coordinates.

Relative to start: The arc center is given in I and J coordinates, relative to the start point of the arc.

Radius (R) values: The arc radius is given (with the address R), rather than the arc center.

Number of decimal: All coordinates are rounded to this number of decimals, and if padding with trailing zeroes is selected below, coordinates are padded with trailing zeroes to this number of decimals.

Trailing 0's:

X123.000: Coordinates are padded with trailing zeroes to the number of decimal selected above, if rounding results in fewer non-zero decimals.

X123.0: Whole numbers are output with one trailing zero. Other coordinates are output rounded to the number of decimals selected above, without trailing zeroes.

X123.: Whole numbers are output with a decimal point, with no trailing zeroes. Other coordinates are output rounded to the number of decimals selected above, without trailing zeroes.

The grid settings are:

Show grid: Select this to have the grid visible.


Show sub-grid: Select this to have a sub-grid visible when zoomed in to a degree that shows few main grid points.


Show origin: Select this to have lines along X and Y zero visible.

Grid size: This sets the spacing between main grid points.

Color configuration

The color configuration is entered by selecting *Colors* in the configuration tree (after entering the configuration and selecting the correct machine type), and scrolling down to the CNC-Calc colors in the list. The color configuration dialog is shown on next page.



To change the color of a CNC-Calc element, either left click the element in the list to select it and click the select color button , or you can double-click the element in the list. The color can then be picked from a standard palette, or a custom color can be defined.

Other configurations that affect CNC-Calc

There are a few other configurations in CIMCO Edit v5 that affect CNC-Calc.

Machine type template: As has already been mentioned, the template used when creating a machine type determines whether the NC code output from CNC-Calc is in ISO or Heidehain conversational.

Machine under file types: In the *Machine* dialog under *File types* in the configuration, the *Comment start*, *Comment end* and *Decimal point* settings are used by CNC-Calc when creating NC code.